

INPAC WP6 Meeting

Investigation of organic dye fluorescence within a photonic crystal structure

$\hbar\omega$



Kasper Baert
Molecular and Nanomaterials



KATHOLIEKE UNIVERSITEIT
LEUVEN

Outline


- Introduction
- Fluorophore as light-emitter
- Spectral narrowing
 - How to achieve
 - Experimental results
- Lifetime investigation
- Future work



KATHOLIEKE UNIVERSITEIT
LEUVEN

Photonic crystals: introduction

- Photonic crystal: refractive index changes periodically thus optical band structure. ¹
- Electronic crystal: electric potential changes periodically thus electronic band structure.
- Photonic crystals suppress spontaneous emission. ²
- A convenient way of fabrication is convective self-assembly. ³




1. E. Yablonovitch, *Phys. Rev. Lett.* **58**, 2059 (1987), S. John, *Phys. Rev. Lett.* **58**, 3485 (1987).
2. E. P. Petrov, V.N. Bogomolov, I. I. Kalosha, S. V. Gaponenko, *Phys. Rev. Lett.* **81**, 77 (1998).
3. P. Jiang, J. F. Bertone, K. S. Hwang, and V. L. Colvin, *Chem. Mater.* **11**, 2132 (1999).




KATHOLIEKE UNIVERSITEIT
LEUVEN

Organic dye as light-emitter



Excitation occurred by
1 ps pulses at 488 nm
wavelength in an
inverted confocal
microscope


Disodium fluorescein was
used as dye



KATHOLIEKE UNIVERSITEIT
LEUVEN

Photonic crystals for spectral narrowing

- We were able to insert a 2D defect into a photonic crystal. ⁴ This was not sufficient to induce spectral narrowing.
- New approach: heterostructure: broader stopband, deeper and wider passband



⁴ K. Wostyn, Y. Zhao, G. de Schaetzen, L. Hellemans, N. Matsuda, K. Clays, A. Persoons *Lanmuir* **19**, 4465-4468 (2003)





KATHOLIEKE UNIVERSITEIT
LEUVEN

Modification of emission by photonic crystal

ABAB heterostructure:

Both suppression and enhancement of emission gives spectral narrowing





KATHOLIEKE UNIVERSITEIT
LEUVEN

Modification of emission by photonic crystal

ABAB heterostructure:

Pronounced miniband features. Emission enhancement remains however, because of omnidirectionality of emission




KATHOLIEKE UNIVERSITEIT
LEUVEN

Effect of photonic bandgap on fluorescence lifetime of fluorescein


Reference photonic crystal

(370 nm)



Sample photonic crystal

(562 nm)



KATHOLIEKE UNIVERSITEIT
LEUVEN

Future Work

- Using quantum dots as the fluorescent species
- Engineering of chromophore location
- Fabrication of inverse opals



Acknowledgments

- **Koen Clays**
- **Renaud Vallée**
- **Branko Kolaric**
- ...

